

ZN610 spare part list

No	Description	QTY	Size/Material	Remarks
1	Up handle	1	PP	
2	Down handle	1	PP	
3	ST serews	2	4*25	
4	switch	2		
5	Top Section	1	PP	
6	Name board	1		
7	Middle section	1	PP	
8	bent connection	1		
9	ST screws	2	3*10	
10	bottom cap	1	PP	
11	spring	1		
12	small cover	1	PP	
13	Up airproof	1		
14	motor	1		
15	Down airproof	1		
16	sponge for bottom section	2	68*25*10	
17	Bottom section	1	PP	
18	screws	6	ST4*18	
19	seal for bottom section	1	Rubber	
20	Safty float valve	1	PP	
21	Filter basket	1	PP	
22	Sponge filter	1		
23	water pipe	1	8*5*650	
24	cover for water can	1	Natural rubber	
25	water can	1		
26	hose connection	1	PP	
27	seal for hose connection	1	rubber	
28	hose seat	1	PP	
29	container	1	PP	
30	pipe storage	1	PP	
31	Base	1	PP	
32	gasket	4	φ 15* φ 6*1.5	
33	screws	4	ST6*25	
34	idler wheel cover	2		
35	idler wheel	2		
36	clasp	2	hardware	
37	gasket	2		
38	connecting rod	1		
39	universal wheel	2		
40	screw	2	ST4*30	
41	screws	4	ST4X14	
42	gasket	4	Φ4	
43	clasp	2	PP	
44	connection	2	POM	
45	protection	10		
46	terminal	10		
47	capacitance	1	0.22uf	
48	inductance	1		
49	tension disc	1	PP	
50	clasp	1		
51	power cable	1		
52	thermal protector	1		
53	pump	1		
54	pump supporting seat	2	rubber	

55	gasket	2	φ 26* φ 8*1	
56	screwa	2	ST4*18	
57	small water pipe	1	φ 6*4*1M	
58	connector	1		
59	fitment	2	ABS	
60	press-button	1	ABS	
61	handle	1	ABS	
62	handle cover 1	1	ABS	
63	handle switch	1		
64	handle cover 2	1	ABS	
65	clasp for metal pipe	2	PP	
66	metal pipe	2		
67	short nozzle	1		
68	hose	1		
69	paper bag	1		
70	triangle brush	1		
71		1		
72		1		
73		2	3*25	
74		1	ABS	
75		1	ABS	
76		4	3*12	
77		1		
78		1	ABS	
79		1	ABS	
80	connecting line	3	0.75*130	
81	connecting line	2	0.75*250	
82	heat-shrinkable tubing	3	25	
83	heat-shrinkable tubing	2	20MM	